




CABINET PARTS

For Models: ET18GMXHW01, ET18GMXHT01
(White) (Biscuit)

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ET18GMXHW01, ET18GMXHT01

(White)

(Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT2201079	Service & Wiring Sheet
	LIT2205478	Energy Label
	LIT2205266	Use & Care Guide
	LIT628370	Modular Icemaker Service Sheet

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

	LIT677969	Do-It-Yourself Manual, Ref./Fzr.
	LIT677971	Do-It-Yourself Manual, Icemaker
2	2189410	Hinge (Top)
3	2166108	Roller-Front (2)
5	489385	Clamp, Tube (Water Supply Line)
6	3400504	Screw
7	2179826	Rivet
12	549193	Clamp-Cord
15	489497	Screw
16	2183972	Hinge, Center
17	2183854	Shim, Hinge Center
18	3400881	Screw
20	2189194	Hinge Butt
21	487576	Washer
23	2172743	Shim, Bottom Hinge
24		Fitting, Water Tube (Not Serviced)
27		Hole Plug (6)
	2201012	White
	2200924	Biscuit
28		Seal, Front (Not Serviced)
30		Seal, Rear (Not Serviced)
35		Corner Filler (2)
	2201014	White
	2200926	Biscuit
36		Grille
	2201009	White
	2201021	Biscuit
38	489341	Washer
39	2189356	Clip-Grille
40		Cover-Hinge
	2160403	White
	2200937	Biscuit
41		Rail, Center (Not Serviced)
44	2189475	Cover, Unit
45		Cabinet (Not a Serviceable Part)


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET18GMXHW01, ET18GMXHT01

(White)

(Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET18GMXHW01, ET18GMXHT01

(White)


(Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #9 & #22)	13		Nameplate	24	2195915	Endcap, Trim
	2183948	White		2175383	White	25	2156003	Endcap, Trim
	2205285	Biscuit		2205769	Biscuit	26	2189202	Bracket, Door
5		Handle Center	14	2195943	Trim, Door Shelf			Stop (2)
	2202807W	White	16	2180027	Trim, Door Shelf	27	488921	Screw
	2202807T	Biscuit	17	8281206	Screw	28		Hole Plug
6	489357	Screw	18	2201052	Trim, Door		844478	White
8	8281146	Screw	19		Freezer Door (Includes #22 & #23)		2200934	Biscuit
9		Door Gasket, Magnetic		2182487	White	29	2156007	Plug-Trim
	2159057	Mist Beige		2205279	Biscuit	30	2156006	Plug-Trim
11	2201051	Trim, Door Shelf	20		Hole Plug	31	2188396	Compartment Door
12		Cover, Screw		2189000	White	33		Handle, F.C.
	2202819W	White		2200936	Biscuit		2202806W	White
	2202819T	Biscuit	22	2183003	Thimble		2202806T	Biscuit
			23		Door Gasket, Magnetic	37	2201050	Trim-Door (2)
				2159327	Mist Beige	41	2156003	Endcap (4)
						42	2195949	Trim, Door

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS

For Models: ET18GMXHW01, ET18GMXHT01
(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS

For Models: ET18GMXHW01, ET18GMXHT01
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	531933	Grommet (2)
3	2189268	Gasket, Evaporator Cover (Side)
4	2193084	Timer, Defrost
5	2212485	Tube-Barrier, Thermostat
6	941839	Hole Plug
7	2187306	Wire Assy. Control Box
8	2162085	Socket, Light (2)
9	2179858	Damper, Air
10	2183833	Fan Motor
11	2163777	Fan Blade
12	2200820	Control Box
13	2200830	Thermostat Assy. (Includes Items 5, 18 & 36)
14	489478	Screw
15	489412	Screw
16	2201170	Cover-Evaporator
17	527949	Light Bulb (2)
18	2200831	Weight, Thermal
19	1118894	Rocker Arm Switch
20	2179859	Post, Damper
21	2176281	Cover, Air Diffuser
22	2200863	Knob, Thermostat
23	2182340	Air Tower
24	2189452	Air Diffuser, Bottom
25	2172565	Freezer Floor
26	2179877	Air Diffuser, Top
29	2200641	Bracket, Fan Motor
30	2189267	Gasket, Evaporator Cover (Top)
31	2204639	Shield, Heat
33	2176341	Clip, Defrost Timer
34	2176297	Knob, Damper
35	2163810	Bracket, Damper Knob
36	2205079	Seal, Rear Thermostat
38	2171931	Release Valve
39	2187301	Wire Assembly, F.C.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

For Models: ET18GMXHW01, ET18GMXHT01
(White) (Biscuit)



UNIT PARTS

For Models: ET18GMXHW01, ET18GMXHT01

(White)

(Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2205341	Plate, Unit Mounting
2	489478	Screw
3	2212599	Condenser
4	2176300	Heater, Defrost
5	2195391	Evaporator Assy.
6	489494	Screw
7	2172619	Drain Pan
8	2182380	Defrost Bi-Metal
9	2176301	Bracket, Heater
10	2163780	Extension, Air Baffle
11	2201184	Support Block
12		Cover
	2162358	Production
	2162358	Service
13		Overload
	2183452	Production (Includes Relay)
	4387938	Service (Includes Relay)
14		Grommet (4)
	1100826	Production
	4387558	Service
15		Relay
	2176740	Production (Service See Overload)

Illus. No.	Part No.	DESCRIPTION
16	489373	Screw
17	2150304	Roller (2)
18	981126	Rivet
19	2182338	Clip, Heater
21		Nut (Not Serviced)
28	2183471	Compressor (Includes Items 12, 13, 15, 29) (Also Order 482801 Installation Kit & 876765 Tube Kit)
29	2199167	Drier
30	2155774	Clamp
39	2198921	Air Baffle
40	2188534	Motor, Condenser
42	2187342	Wire Assy. Unit
43	2190685	Fan Blade
44	486692	Nut
45	2212603	Tube, Transition
46	2205294	Tube, Discharge
47	2205293	Tube, Suction
48	2212848	Tube, Process
58	2200946	Evap. Tray

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated and Optional Parts Not Included		
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")
	482278	Start Kit

REFRIGERANT CHARGE


3.75 Ozs.
(R134A)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ET18GMXHW01, ET18GMXHT01
(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ET18GMXHW01, ET18GMXHT01
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
3	488878	Clamp, Tube
4	2181939	Insert, Tube
5	628379	Clip, Fuse
7	2181943	Tube Water
9	489478	Screw, 8 x 1/2
10	2182104	Valve Solenoid
11	627018	Nut Compression
18	2174157	Cover
19	3400881	Screw
20	628228	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
22	628356	Cup, Water Fill
23	2194711	Ejector
24	2182124	Ice Stripper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	489322	Screw
30	489276	Screw
31	627792	Shut Off Arm
32	628256	Harness, Wiring
33	628320	Bracket
35	628399	Module Assembly (Includes Item 38)
38	489136	Screw, 3-24 x 23/64
39	488208	Screw, 8 x 13/16
40	488886	Screw, 8-18 x 1/2
100	626636	Complete Icemaker Assembly


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: ET18GMXHW01, ET18GMXHT01

(White)

(Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	2210522	Shelf, Ladder (2)
2	2202821	Shelf, Ladder Center
3	2177824	Glass, Full Shelf
4	2163835	Track, Crisper
5	489478	Screw
6	2163762	Cup, Shelf Mounting
7	2201101	Shelf, Cantilever
8	2201097	Trim, Shelf
9	2195342	Cover, Crisper
10	2182730	Egg Bin
11	2169921	Insert, Crisper Cover
12	2201105	Pan Shelf, Cantilever
14	2169917	Glass, Meat Cover
15	2172541	Crisper Support
16	2201103	Shelf, Full Cantilever
17	2189453	Shelf, Freezer
18	2193394	Trim, Shelf Rear
19	2201022	Pan, Crisper
20	2201031K	Pan, Meat
22	2176219	Pan, Ice
23	2201135	Trim, Shelf Front
24	2201023	Pan, Crisper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: ET18GMXHW01, ET18GMXHT01

(White)

(Biscuit)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Parts Not Illustrated and
Optional Parts (Not Included)

Miscellaneous

PARTS NOT ILLUSTRATED

978941	Insulation, Fiberglass (63-1/2" x 35-1/2" x 2-5/8")
212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4" x 108")
876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")
876370	Kit, Insulation (2 Pcs. 3" x 24" x 48")
876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")
505587	Sealer, Mastic (1 Qt.)
511873	Touch-Up, White Porcelain (2 Oz.)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1-1/4 Oz.)
606755	Bag, Insulation (36-5/8" x 46")
799833	Kit, Evaporator Repair (Aluminum Epoxy)
799832	Kit, Porcelain Repair (White)
503695	Cork Sealer (1/4 Pound)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Customer Touch-Up Material

*350942	Primer, White (13 Oz. Spray Can)
*350939	Enamel, Black (13 Oz. Spray Can)
*350930	Enamel, White (13 Oz. Spray Can)
*350956	Enamel, Almond (13 Oz. Spray Can)
72017	Brush Touch-Up Kit (White)
72032	Brush Touch-Up Kit (Black)
72107	Brush Touch-Up Kit (Almond)

Refinishing Material

799344	Enamel, White (1 Qt. Uncut)
978883	Enamel, Almond (1 Qt. Uncut)
833938	Kit, Terminal Connector

* **CAUTION:** The spray paint is not to be used where the paint may make contact with the door gaskets.

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ICE MAKER FIELD INSTALLABLE

ECKMF94

TORX SCREW WRENCH

1117510 Torx Key